

Re: Debugger is "Unattached"!

Source: <http://newsgroups.derkeiler.com/Archive/Comp/comp.os.vxworks/2007-08/msg00022.html>

- *From:* ganyong <ganyong2000@xxxxxxxxxx>
 - *Date:* Tue, 07 Aug 2007 05:17:31 -0700
-

On 8 7 , 2 05 , TheBeast! <member1...@xxxxxxxxxxxxxxxxxxxxxxxxxx> wrote:

Hi everybody ,

I have a target system on Vmware and may PC as the Host. The VxWorks runs successfully on target. I can luanch the TargetServer successfully too. All things seems ok , but , when I run the Debugger it shows the following message at the butten of its window :

192.168..100@NR : Unattached

What's wrong ? How can I debug my VxWorks?

--

When you need to debug certain task , you need attach the task. You can find the command in debug menu.
However, if you need to debug multi task enviroment or interrupt, you need to attach to the system.

.